



STED X

RIFLESCOPES

User Manual

DEAR VALUED CUSTOMER;

Thank you for choosing one of our STED X Products.

We appreciate your trust and confidence in our brand. Your satisfaction is our top priority, and we are committed to delivering high-quality products that meet your needs.

If you have any questions or need further assistance, please do not hesitate to reach out to our customer support team. We are always here to help.

Thank you once again for your purchase. Enjoy your new product!



LIFETIME WARRANTY



30 Day FREE Returns
Satisfied or refunded.

TABLE OF CONTENTS

02	Contents	12	Zeroing your scope
03	Product Overview	13	Care & Maintenance
04	Package Incl.	14	Warranty Information
05	Features & Models		
07	Mounting Instructions		
10	Eye-piece Focussing		
11	Windage & Elevation Turret Adjustment		

1. PRODUCT OVERVIEW:

Eyepiece

Magnification Ring (Adjustment)

Elevation Turret (screw on cap)

Windage Turret (screw on cap)

25.4mm Main Tube

Objective Bell

Objective Lens

¼ inch MOA Turret Adjustments

2. PACKAGE INCLUDES:

- Riflescope x 1
 - Lens Cloth x 1
 - Pair of Mid-height 3/8th Dovetail Mounts
 - Allen Key x 1
 - Protective end caps
-

3. INTRODUCTION:

Welcome to the Bull Proof Community! We are super stoked to have you onboard, and hope you love your new STED X Riflescope.

The STED X range was developed to deliver reliable, high-quality optics that any shooter can trust.

Built for consistent performance in the field, every STED X scope is backed by our **Lifetime Warranty** and **Satisfied or Refunded Guarantee** - ensuring complete confidence in your new Bull Proof optic.

4. FEATURES:

- ✔ Green Multi-Coated Lens
- ✔ Second Focal Plane Optic
- ✔ Crisp Duplex Reticle
- ✔ Aircraft Grade Aluminium
- ✔ Included Mid-Height 3/8th Dovetail Mounts
- ✔ Removable Protective End Caps
- ✔ Included Cleaning Lens Cloth
- ✔ Backed by a Lifetime Warranty

5. STED X MODELS:

Model	Focal Plane	Turret Adj.	Tube Diam.	Objective Diam.	Eye Relief	Reticle
3-9x32	Second (SFP)	¼ MOA	25.4mm (1")	32mm	80mm	Duplex
3-9x40	Second (SFP)	¼ MOA	25.4mm (1")	40mm	80mm	Duplex
4-12x44	Second (SFP)	¼ MOA	25.4mm (1")	44mm	80mm	Duplex

6. MOUNTING INSTRUCTIONS:

CAUTION : When mounting your scope, always ensure that your firearm is NOT loaded and no ammunition is present in the area. We recommend that your scope should always be mounted by an experienced professional.

Preparing your Firearm & Components:

1. Ensure the firearm is completely unloaded and the chamber is clear before beginning.
2. Place the rifle on a stable gun vise or rest to keep it secure during installation. Check with a level.
3. Confirm that your scope rings and bases are compatible with both the rifle and the scope tube diameter.
4. Lightly clean mounting surfaces to remove oil, dust or debris.

Attaching the Lower Ring Halves: :

1. Install the lower halves of the scope rings onto the mounted bases or rail system.
2. Position them far enough apart to properly support the scope without contacting the turrets or objective bell.
3. Tighten the ring-to-base fasteners to secure.

6. MOUNTING INSTRUCTIONS:

Positioning the Riflescope:

1. Carefully place the riflescope into the lower ring halves.
2. Move the scope forward/backward to achieve proper eye relief.
3. Ensure the rings are not obstructing any components of the scope and there is a suitable distance between the magnification ring, turrets and objective bell.
4. Ensure the riflescope is not obstructing or touching against any components of the firearm.

Level the Scope/Reticle & Install Upper Ring Halves:

1. Use a bubble level to ensure the scope and firearm are exactly level.
2. Check the reticle to ensure it is level.
3. Place the upper ring halves over the scope.
4. Insert screws and tighten them gradually in an alternating cross pattern (similar to tightening wheel nuts).

I 6. MOUNTING INSTRUCTIONS:

Post-Mounting Checks:

1. Cycle the rifle bolt to ensure proper clearance with the scope.
2. Confirm the objective bell clears the barrel.
3. Check that the magnification ring rotates smoothly.
4. Inspect all fasteners again after your first shooting session, as screws may settle slightly.

Important Considerations:

1. Never over-tighten scope rings, as this can damage the scope tube or internal components.
2. Always use a quality inch-pound torque wrench when installing optics.
3. Re-check mounting screws periodically to ensure they remain secure.
4. Always ensure your rings are the correct size to suit the scope tube diameter.

7. EYEPIECE FOCUSING:

The eyepiece focus allows you to adjust the clarity of the reticle (crosshair) to suit their individual eyesight. By rotating the eyepiece, the reticle becomes sharp and clearly defined, ensuring quicker target acquisition and reducing eye strain during use.

1. Hold the scope and look through the eyepiece.
2. Ensure the reticle appears sharp and well-defined. If it does not, proceed with adjustments.
3. Rotate the eyepiece in either direction to adjust the reticle's sharpness. (NOTE : This piece can feel stiff to move, this is purposefully done to ensure it doesn't move once set and in use).
4. If the reticle's focus improves but is not perfect, continue rotating in the same direction.
5. If the reticle's focus worsens, rotate the bell in the opposite direction until the reticle is sharp and clear.

NOTE: If not already done, you will need to remove (pull off) the rubber end protective caps to access the eye piece and make the necessary adjustments.

8. ADJUSTING WINDAGE & ELEVATION TURRETS:

Windage Turret :

Located on the right side of the scope. Screw off the cap to make adjustments.

This turret is responsible for controlling the horizontal point of impact of the bullet. Turning this turret moves the shot left or right on the target, allowing you to correct shots that land either side of the target centre. **Turn clockwise to move left, and counter-clockwise to move the point of impact right.**

Elevation Turret :

Located on the top of the scope. Screw off the cap to make adjustments.

This turret is responsible for controlling the vertical point of impact of the bullet. Turning this turret moves the shot up or down on the target, allowing you to compensate primarily for bullet drop at longer distances. **Turn clockwise to lower, and counter-clockwise to raise the point of impact.**

1. Remove the turret caps.
2. Identify the adjustment direction marked on each turret.
3. Make small adjustments to either your elevation and/or windage turrets - this is measured in noticeable 'clicks'. These 'clicks' represent $\frac{1}{4}$ of an inch movement at 100 yds.

9. INSTRUCTIONS FOR ZEROING THE SCOPE:

CAUTION: It is imperative that these steps are performed in a safe and approved rifle range. Always follow safe firearm handling practices. If unsure of this process, seek assistance from a professional.

Before you start :

We recommended you bore sight your rifle to ensure your scope and barrel are both aligned at the intended point of impact on your target. Information for this process should be supplied with your bore sight.

Sighting in your new scope :

1. Set your target up at your desired zeroing distance (commonly 50m or 100m)
2. Stabilise the firearm using a rest or bipod to minimise movement.
3. Fire a 3-shot group at the centre of the target
4. Check the point of impact and determine how far the average is from the target centre.
5. Adjust your elevation and windage turret as needed to move the point of impact.
6. Repeat until impact is consistently hitting desired target.
7. Screw caps back on to protect the turrets.

| 10. CARE AND MAINTENANCE:

By following these care instructions, you will maintain the clarity and functionality of your scope, ensuring optimal performance and longevity.

- Keep lenses clean using the supplied soft lens cloth or lens brush to remove dust and debris.
 - Avoid touching the glass with fingers to prevent oils or smudges on the lens.
 - Use lens caps when the scope is not in use to protect the optics.
 - Store in a dry place to prevent moisture or condensation buildup.
 - Check mounting screws periodically to ensure the scope remains securely mounted.
- Avoid harsh chemicals when cleaning; use only lens-safe cleaning solutions if required.
 - Protect from heavy impacts or drops which may affect internal alignment.
 - Wipe down the scope body with a clean cloth after exposure to rain, dust, or mud.
 - Inspect turrets and caps occasionally to ensure they are secure and functioning correctly.

WARRANTY INFORMATION

At Bull Proof, we stand behind the quality and reliability of our products. Every STED X riflescope is backed by our Lifetime Warranty and Satisfied or Refunded Guarantee, giving you complete confidence in your purchase.

Our lifetime warranty will cover you against manufacturing defects and workmanship faults. If your scope experiences a fault under normal use, Bull Proof will repair or replace the product at our discretion.

What the Warranty Covers

- Manufacturing defects
- Mechanical faults under normal use
- Optical defects affecting performance

What the Warranty Does Not Cover

- Damage caused by misuse, abuse, or improper installation
- Damage resulting from accidents, impacts, or unauthorised modifications
- Cosmetic damage that does not affect the function of the scope

If you experience any issues with your riflescope, please contact the Bull Proof support team with proof of purchase and a description of the problem. Our team will guide you through the next steps to resolve the issue quickly and efficiently.

sales@bullproof.com.au | (03) 9125 7069 | 1 Rawanne Close, Pakenham, 3810

